



Model 418-1 Adjustable Lifting Bridle

September, 2010 GLO
Pub. No. 234-0234-04



*Read this Manual
and Retain for
Future Reference*

Ferno Technical Support

Customer service and product support are important aspects of each Ferno product. For technical support questions:

Telephone (Toll-free)	1.800.733.3766 ext. 1010
Telephone	1.937.382.1451 ext. 1010
Email	quality.products@ferno.com

Ferno Customer Relations

For ordering assistance or general information:

CANADA AND THE U.S.A.

Telephone (Toll-free)	1.877.733.0911
Telephone	1.937.382.1451
Fax (Toll-free)	1.888.388.1349
Fax	1.937.382.1191
Internet	www.ferno.com

ALL OTHER LOCATIONS

For assistance or information, please contact your Ferno distributor. If you do not have a Ferno distributor, please contact Ferno Customer Relations:

Ferno-Washington, Inc.

70 Weil Way

Wilmington, Ohio 45177-9371, U.S.A.

Telephone	+1.937.382.1451
Fax	+1.937.382.6569
Internet	www.ferno.com

EUROPEAN REPRESENTATIVE

Ferno (UK) Limited

Stubs Beck Lane, Cleckheaton

West Yorkshire BD19 4TZ, United Kingdom

Telephone	+44 (0) 1274 851999
Fax	+44 (0) 1274 851111
Internet	www.ferno.co.uk

Disclaimer

This manual contains general instructions for the use, operation and care of this product. The instructions are not all-inclusive. Safe and proper use of this product is solely at the discretion of the user. Safety information is included as a service to the user. All other safety measures taken by the user should be within and under consideration of applicable regulations. It is recommended that training on the proper use of this product be provided before using this product in an actual situation.


Retain this manual for future reference. Include it with the product in the event of transfer to new users. Additional free copies are available upon request from Customer Relations.

Proprietary Notice

The information disclosed in this manual is the property of Ferno-Washington, Inc., Wilmington, Ohio, USA. Ferno-Washington, Inc. reserves all patent rights, proprietary design rights, manufacturing rights, reproduction use rights, and sales use rights thereto, and to any article disclosed therein except to the extent those rights are expressly granted to others or where not applicable to vendor proprietary parts.

Limited Warranty Statement

The products sold by Ferno are covered by a limited warranty, which is printed on all Ferno invoices. The complete terms and conditions of the limited warranty, and the limitations of liability and disclaimers, are also available upon request by calling Ferno at 1.800.733.3766 or 1.937.382.1451.



USERS' MANUAL

To request additional free users' manuals, contact Ferno Customer Relations, your Ferno distributor, or visit www.ferno.com.


TABLE OF CONTENTS

Section	Page	Section	Page
Ferno Customer Relations	2	4 - Bridle Features	7
Ferno Technical Support	2	4.1 Color-Coded Webbing	7
1 - Safety Information	4	4.2 Bridle Length Adjustment	7
1.1 Warning	4	4.3 Carabiners	8
1.2 Important	4	5 - Using the Bridle	9
1.3 Bloodborne Disease Notice	4	5.1 Before Placing the Bridle in Service	9
1.4 Safety and Instruction Labels	4	5.2 General Guidelines for Use	9
1.5 Symbol Glossary	4	5.3 Horizontal Lifting/Lowering	10
2 - Operator Skills and Training	5	5.4 Vertical Lifting/Lowering	11
2.1 Skills	5	6 - Maintaining the Bridle	12
2.2 Training	5	6.1 Maintenance Schedule	12
3 - About the Bridle	6	6.2 Disinfecting and Cleaning the Bridle	12
3.1 Description	6	6.3 Lubricating the Carabiners	12
3.2 General Specifications	6	6.4 Inspecting the Bridle	13
3.3 Bridle Components	6	6.5 Storing the Bridle	13
		Training Record	14
		Maintenance Record	15

1 - SAFETY INFORMATION

1.1 Warning

Warning notices indicate a potentially hazardous situation which, if not avoided, could result in injury or death.

 WARNING
<p>Untrained operators can cause injury or be injured. Permit only trained personnel to operate the bridle.</p> <p>Improper use of the bridle can cause injury. Use the bridle only for the purpose described in this manual.</p> <p>Improper operation can cause injury. Operate the bridle only as described in this manual.</p> <p>An unrestrained or improperly restrained patient can be injured. Secure the patient in the basket stretcher with a restraint system suitable to the rescue situation.</p> <p>Modifying the bridle can cause injury and damage. Use the bridle only as manufactured by Ferno.</p> <p>Improper maintenance can cause injury. Maintain the bridle only as described in this manual.</p>

1.2 Important

Important notices emphasize important usage or maintenance information.

Important

1.3 Bloodborne Disease Notice

To reduce the risk of exposure to bloodborne diseases such as HIV-1 and hepatitis when using the bridle, follow the disinfecting and cleaning instructions in this manual.

1.4 Safety and Instruction Labels

Safety and instruction labels place important information from the users' manual on the bridle. The label below is affixed to two legs of the bridle.

BRIDLE CAPACITY 600 LB/272 KG TOTAL WEIGHT

1.5 Symbol Glossary

The symbols defined below are used on the bridle and in this users' manual. Ferno uses symbols recognized by the International Standards Organization (ISO), American National Standards Institute (ANSI) and the emergency medical services industry.



General Warning of Potential Injury



Standard Load Limit



Read the Users' Manual



Product meets European Union Standards

2 - OPERATOR SKILLS AND TRAINING

2.1 Skills

Operators using the bridle need:

- a working knowledge of emergency patient-handling procedures.
- the ability to assist the patient.

2.2 Training

Operator trainees need to:

- receive professional instruction and training in rescue procedures using lifting bridles.
- read and understand this manual.
- be trained on the use of the bridle.
- practice with the bridle before using it with a patient.
- record their training information. A sample training record sheet is provided on page 14.



WARNING

Untrained operators can cause injury or be injured. Permit only trained personnel to operate the bridle.

Important

Rescue procedures using the lifting bridle require special skills and are potentially hazardous activities. No rescue personnel should attempt such rescue procedures unless they have received professional instruction and training.

3 - ABOUT THE BRIDLE


3.1 Description

The Model 418-1 Adjustable Lifting Bridle (called the bridle in this manual) is designed to be used as an interface between a basket stretcher and a rope hoist, cable, or other lifting device.

The bridle is compatible with the Ferno® Models 71, 71-S, and 71-SS Basket Stretchers.

⚠ WARNING

Improper use of the bridle can cause injury. Use the bridle only for the purpose described in this manual.



Load Limit

Inspect the bridle if the load limit has been exceeded (See *Inspecting the Bridle*, page 13).


3.2 General Specifications

“D” Lift Ring	3" x 2-5/8" (76 mm x 67 mm)
Webbing Width	1-3/4" and 1" (44 mm and 25 mm)
Leg Length	
Lift Ring to Carabiner	54-1/2" (1384 mm)
Individual Legs	34-1/2" (876 mm)
Range of Adjustment	11" (279 mm) per branch
Leg Separation	100" (254 cm) maximum
	between gray and orange legs
Temperature Range	-40°F to 140°F (-40°C to 60°C)
Weight	5 lb (2 kg)
Load Limit	600 lb (272 kg)

General specifications are rounded to the nearest whole number. Metric conversions are calculated before rounding the Imperial measurements. For more information, contact Ferno Customer Relations (page 2) or your Ferno distributor.

Ferno reserves the right to change specifications without notice.

3.3 Bridle Components



Storage Pouch (not to scale)



Users' Manual
234-0234

4 - BRIDLE FEATURES

4.1 Color-Coded Webbing

The center section of the bridle divides into two branches of 1-3/4 in. (44 mm) webbing.

Each branch terminates with a “V” ring assembly that serves two purposes: it is used to adjust the branch length, and it is the attachment point for two legs of one-inch (25 mm) webbing.

The pair of legs attached to one branch is orange and the pair of legs attached to the other branch is gray.

For horizontal lifting, attach the orange legs to the grommets on opposite sides of one end of the stretcher, and attach the gray legs to the grommets on opposite sides of the other end of the stretcher (Figure 1). This arrangement allows adjustment of the bridle length but keeps the stretcher level side-to-side.

Important

Do not attach straps of the same color to the same side of the stretcher. Doing so will cause the stretcher to tilt to one side when the straps are shortened or lengthened. Always attach straps of the same color to the same end of the stretcher.



Figure 1 - Placement of Color-Coded Legs

4.2 Bridle Length Adjustment

Adjusting the length of a branch changes the elevation at the end of the stretcher attached to that branch. The length of each branch of the bridle may be shortened as much as 11 in. (279 mm).

SHORTENING THE BRIDLE

To shorten a branch of the bridle, hold the “V” ring perpendicular to the webbing and pull the bottom layer of webbing backward through the “V”-ring slide assembly until the branch is the desired length (Figure 2).

Pulling the bottom layer of webbing allows the slack portion of webbing to hang toward the inside of the bridle where it is less likely to snag on elements encountered in a rescue situation.

RETURNING THE BRIDLE TO FULL LENGTH

To return a branch of the bridle to its full length, grasp the branch with one hand and with the other hand pull the “V” ring until no slack remains in the branch webbing (Figure 3).



Figure 2 - Shortening the Bridle



Figure 3 - Returning the Bridle To Full Length

4.3 Carabiners

Each bridle leg terminates with a locking carabiner (Figure 4). To open the carabiner:

1. Rotate the screw-type locking sleeve to uncover the nose.
2. Squeeze the gate open and slide the nose of the carabiner through a tie-in point (grommet) on the basket stretcher (Figure 5).

Note: Normally, a carabiner is oriented with the gate toward the inside of the stretcher to prevent the gate being opened by rubbing against a cliff face, building, rock or other element encountered during a rescue. However, certain situations may dictate the opposite orientation. It is the responsibility of the user to know which orientation is best suited to a given situation.

To secure the carabiner:

1. Release the gate.
2. Rotate the locking sleeve until it covers the nose and stops traveling (Figure 6).




Figure 4 - Carabiner Components




Figure 5 - Attach the Carabiner With the Gate Facing the Inside of the Stretcher




Figure 6 - Carabiner Gate Locked Closed

5 - USING THE BRIDLE

5.1 Before Placing the Bridle in Service

- Personnel who will work with the bridle need to read this manual.
- Confirm that the bridle operates properly by operating it according to instructions in *Bridle Features*, pages 7 and 8, and *Inspecting the Bridle*, page 13.

5.2 General Guidelines for Use

- Rescue procedures using the lifting bridle require special skills and are potentially hazardous activities. No rescue personnel should attempt such rescue procedures unless they have received professional instruction and training.
- Because rescue situations are rarely the same, this manual must be general in nature. It is the responsibility of personnel specially trained in technical rescue to know the techniques involved and to select the lifting equipment, stretcher, and patient restraint system suitable for each rescue situation.
- Make sure all equipment used with the bridle has a load rating at least equivalent to that of the bridle.
- Anytime a bridle is used in conjunction with a stretcher to lift a victim, the stretcher may be suspended horizontally, vertically, or at an angle, and rescuers may slide or carry it at various angles. Secure the patient in the stretcher so that he or she does not slip lengthwise, slide from side to side, or come out of the stretcher.

WARNING

Improper operation can cause injury. Operate the bridle only as described in this manual.

WARNING

An unrestrained or improperly restrained patient can be injured. Secure the patient in the basket stretcher with a restraint system suitable to the rescue situation.

WARNING

Modifying the bridle can cause injury and damage. Use the bridle only as manufactured by Ferno.

Important

Rescue procedures using lifting bridles and other specialized gear are considered technical in nature. They are potentially hazardous activities and require special skills. No rescue personnel should attempt technical rescue procedures unless they have received professional instruction and training.

Important

Personnel using the bridle in a technical-rescue situation are responsible for knowing the techniques involved and for selecting the bridle, stretcher, and patient restraint system best suited to the rescue situation.

5.3 Horizontal Lifting/Lowering

Read the *General Guidelines for Use*, page 9, before using the bridle.

USING THE COLOR-CODED WEBBING

For proper hookup, both orange legs must be attached to opposite sides of the same end of the stretcher (either the head end or the foot end) and both gray legs must be attached to opposite sides of the other end of the stretcher (Figure 7). See page 7 for more information about the color-coded webbing.

Important

Do **not** attach webbing of the same color to the same side of the stretcher. Doing so can cause the stretcher to tilt to one side when the bridle length is adjusted. Always attach webbing of the same color to the same end of the stretcher.

ATTACHING THE CARABINERS

The Ferno® Models 71, 71-S, and 71-SS Basket Stretchers are fitted with four grommetted tie-in points for the bridle (Figure 8).

Attach the carabiners to the tie-in points (see page 8 for carabiner operating instructions).

Tie-in points on basket stretchers not manufactured by Ferno-Washington, Inc., may vary in type and location. Follow the stretcher manufacturer's instructions for choosing and using tie-in points.

Adjust the length of the branch webbing until the basket stretcher is level. See length adjustment instructions on page 7.

USING TAG LINES

Attach tag lines to the stretcher to allow rescuers to position or maneuver the stretcher and to prevent it from spinning (Figure 9).



Figure 7 - Attaching the Orange and Gray Legs At Opposite Ends of the Stretcher




Figure 8 - Grommets at Tie-In Points on the Ferno® Models 71, 71-S, and 71-SS Basket Stretchers




Figure 9 - Horizontal Lifting/Lowering

5.4 Vertical Lifting/Lowering

Read the *General Guidelines for Use*, page 9, before using the bridle.

USING THE COLOR-CODED WEBBING

For vertical lifting, tie-in points on Ferno® Models 71, 71-S, and 71-SS Basket Stretchers are the head-end handholds. For proper hookup, use all four legs of the bridle, placing an orange leg and a gray leg at each of the two head-end handholds (Figure 10.)

ATTACHING THE CARABINERS

To attach a leg, open the carabiner gate, slide the carabiner nose through the handhold opening, and lock the carabiner around the basket rim and metal frame. See page 8 for carabiner operating instructions.

Adjust the length of the branch webbing until the weight of the basket stretcher is held equally by each leg pair.

Tie-in points on stretchers not manufactured by Ferno-Washington, Inc., may vary in type and location. Follow the stretcher manufacturer’s instructions for choosing and using tie-in points.

TAG LINES

Attach tag lines to the stretcher to allow rescuers to position or maneuver the stretcher and to prevent it from spinning (Figure 10).




Figure 10 - Vertical Lifting/ Lowering

6 - MAINTAINING THE BRIDLE

6.1 Maintenance Schedule

The bridle requires regular maintenance. Set up and follow a maintenance schedule. The table at right represents minimum intervals for maintenance.

Keep maintenance records. A sample maintenance record sheet is provided on page 15.

When using maintenance products, follow the manufacturers' directions and read the manufacturers' material safety data sheets. You can purchase a recommended disinfectant from your Ferno distributor or Ferno Customer Relations (page 2).

6.2 Disinfecting and Cleaning the Bridle

1. Remove the bridle from the basket stretcher.
2. **To disinfect:** Apply disinfectant to all surfaces of the bridle, following the manufacturer's instructions for application method and contact time.
3. **To clean:**
 - o Wash the bridle by hand using warm, soapy water.
 - o Rinse in clear water.
 - o Use towels to squeeze excess water from the webbing and to wipe excess water from the hardware and carabiners.
 - o Hang the bridle in a warm place to dry.
 - o When webbing, hardware, and carabiners are completely dry, lubricate the carabiners as described below.

6.3 Lubricating the Carabiners

As needed, lubricate the carabiner hinge pins, latches, springs, and locking sleeves using a multi-purpose grease, or a synthetic lubricant such as WRL-191S.

Use a small amount of lubricant.

Wipe off excess lubricant.

 **WARNING**

Improper maintenance can cause injury. Maintain the bridle only as described in this manual.

Minimum Maintenance Intervals	Each Use	As Needed	Each Month
Disinfecting (this page)	•		
Cleaning (this page)		•	
Lubricating (this page)		•	
Inspecting (page 13)	•		

Important

Disinfectants and cleaners containing bleach, phenolics, or iodines can cause damage. Do not use products containing these chemicals.

6.4 Inspecting the Bridle

After each use, have your service’s equipment maintenance personnel inspect the bridle, following the checklist at right.

If inspection shows damage or excessive wear, remove the bridle from service and replace it with a new bridle.

6.5 Storing the Bridle

Store the bridle in a dry place, away from direct sunlight.

INSPECTION CHECKLIST

- Are all components present?
- Is all webbing in good condition with no cuts or frayed edges?
- Is webbing stitching in good condition with no frayed or broken threads?
- Are the “V” rings and lift ring true to their original forms and free of cracks, deep scratches, and gouges?
- Do moving parts of the “V” rings move smoothly?
- Are the carabiners true to their original form?
- Are the carabiners free of cracks, deep scratches, and gouges? (Check to make sure that what appears to be a scratch is not actually a crack.)
- Are carabiner hinge pins securely in place?
- Do the carabiner locking sleeves turn smoothly and latch the gates securely?

